

## Installation

The GfG G450 Simulator is a software program which simulates most of the G450 operations on a PC.

The software does not require formal installation.

Simply download the ZIP file below and extract it to a folder of your choice.

The ZIP file contains 3 files which must all be saved (extracted) to the same folder.

Once extracted and saved simply double-click on the file named G450Sim.exe or G450Sim to run the program

Click to Download: [G450\\_Simulator](#)

## Operation

Once the G450 Simulator Program is loaded an image will appear which depicts the top of the G450 (upper half) and a control panel (lower half).

To start the simulator press the button with the green dot.

The controls panel may be used to change the concentrations of gas that the instrument is exposed to (O<sub>2</sub>, LEL, H<sub>2</sub>S and CO) as well as the battery capacity (voltage).

